Wiring Diagram - 700 Series

Connect the power harness (006-765IC) to the tractor battery (12 volt) using the red wire with fuse to the positive side
and the black wire to the negative.



A. The power harness must be connected to the battery!

CONTACT HARVEST TEC BEFORE MODIFICATIONS.

The unit will draw more amps than convenience outlets can handle. Any modifications of the power harness will void systems warranty

- B. This unit will not function on positive ground tractors.
- C. If the unit loses power while operating it will not keep track of accumulated pounds of product used.
- 2. The power harness on the tractor (006-765IC) will run from the tractor battery to the hitch. The power harness on the baler (006-765B) will connect to the tractor power harness (006-765IC) at the hitch.
- 3. Connect the red keyed power wire (006-765CPH) to a keyed power source on the tractor. Connect the black keyed power wire to ground.

The keyed power wire must connect to a keyed source or the unit will not power up correctly.

- 4. Attached the ISO Communication Module (006-6673) to the tractor power harness (006-765IC).
- 5. Attach the End of Bale (EOB) connection on baler harness (006-765B) to the EOB Sensor (006-7401).
- 6. Attach star wheel (030-4642 U/UE) connection to ISO Pump Module on pump plate assembly.

System Wiring Diagram

