

System Wiring

1. Locate the wiring harness (006-765IDM) supplied in the 740 dye Sprayer Marking Kit. Attached 12 pin plug into module mounted on the metal frame of the dye marker.
2. Plug uncapped triangle plug into plug on metal frame.
3. Run Dye Marking harness down to main applicator harness (006-765B or 006-765B2) and attach it to one of the two CAN plugs.

System Wiring Diagram

