

OWNER'S MANUAL

Model 870 SCANNER REMOTE FLOOR SWITCH




P.O. Box 63 • 2821 Harvey Street • Hudson, WI 54016
800-635-7468 • www.harvesttec.com

REVISED 4-10

INSTALLATION INSTRUCTIONS

1. Attach the harness from the 870 Scanner Remote Floor Switch to the port on the right side of the 860 Scanner





2. Attach switch bracket to a location on the floor that is accessible to foot operation with hardware included.

OPERATION

Your 860 Scanner will operate in the same manner as it did before. Refer to your 860 Scanner Operators Manual for instructions and operation.

NOTE: There is no voltage/current in this system. The buttons are detected with an electrical “ground sense”. The switch is normally open and temporarily closed when the button is pushed. If the buttons do not work, check connectors and wire continuity with the appropriate meter.

HARVEST TEC MODEL 870 PARTS BREAKDOWN



<u>Ref</u>	<u>Description</u>	<u>Part#</u>	<u>Qty</u>
1	Foot Switch Mount	001-LM01	1
2	Switch	012-1014	2
3	Cable	006-8601C2	1
4	Cable Clamp	008-9011	1
NP	6/32 x 3/8 PHMS		4
NP	6/32 Nylock Nut		4
NP	5/16 x 1 1/4 Self Tapper		2
NP	5/16 x 3/4 Bolt		2
NP	5/16 Lock Washer		2
NP	5/16 Nut		2
NP	1/4 x 3/4 Bolt		1
NP	1/4 Nylock Nut		1
NP	8" Cable Ties		5

WARRANTY AND LIABILITY AGREEMENT

Harvest Tec, Inc. will repair or replace components that are found to be defective within 12 months from the date of manufacture. Under no circumstances does this warranty cover any components which in the opinion of Harvest Tec, Inc. have been subjected to negligent use, misuse, alteration, accident, or if repairs have been made with parts other than those manufactured and obtainable from Harvest Tec, Inc.

Our obligation under this warranty is limited to repairing or replacing free of charge to the original purchaser any part that in our judgment shows evidence of defective or improper workmanship, provided the part is returned to Harvest Tec, Inc. within 30 days of the failure. Parts must be returned through the selling dealer and distributor, transportation charges prepaid.

This warranty shall not be interpreted to render Harvest Tec, Inc. liable for injury or damages of any kind, direct, consequential, or contingent, to persons or property. Furthermore, this warranty does not extend to loss of crop, losses caused by delays or any expense prospective profits or for any other reason. Harvest Tec, Inc. shall not be liable for any recovery greater in amount than the cost or repair of defects in workmanship.

There are no warranties, either expressed or implied, of merchantability or fitness for particular purpose intended or fitness for any other reason.

This warranty cannot guarantee that existing conditions beyond the control of Harvest Tec, Inc. will not affect our ability to obtain materials or manufacture necessary replacement parts.

Harvest Tec, Inc. reserves the right to make design changes, improve design, or change specifications, at any time without any contingent obligation to purchasers of machines and parts previously sold.

Revised 01/03/06

HARVEST TEC, INC.
P.O. BOX 63
2821 HARVEY STREET
HUDSON, WI 54016
PHONE: 715-386-9100
1-800-635-7468
FAX: 715-381-1792
Email: info@harvesttec.com