



Parts Breakdown for Star Wheel Sensor and Hoses



| <u>Ref</u> | <u>Description</u> | <u>Part#</u> |
|------------|-------------------------|--------------|
| 1. | Block cover | 006-4641B |
| 2. | Electronic swivel | 006-4642A |
| 3. | Swivel insert | 006-4642B |
| 4. | Snap ring | |
| 5. | Washer | |
| 6. | Dust seal | |
| 7. | Plug fitting | 003-F38 |
| 8. | Wiring grommet | 008-0821A |
| 9. | Star wheel block | 006-4641A |
| 10. | Star wheel sensor | 006-4641C |
| 11. | Twine guard-left | 001-4645 |
| | Twine guard-right(prox) | 001-4644 |
| | Star wheel assembly | 030-4641 |

*****Note: Star wheel assembly includes Ref#'s 1-10.



| <u>Ref</u> | <u>Description</u> | <u>Part#</u> |
|------------|--------------------------------------|--------------|
| 1A. | 1/4" Hose-clear | 002-9006 |
| 1B. | 1/4" Hose-light blue | 002-9006 |
| 1C. | 1/4" Hose-green | 002-9006 |
| 2. | 3/8" Hose (filter to pumps) | 002-9003 |
| 3. | 1/2" Hose (tank to filter) | 002-9001 |
| 4. | 3/4" Hose (tank to drain/fill valve) | 002-9002 |

Note: When ordering hose make sure indicate which color of hose you want.