


PARTS BREAKDOWN FOR CONTROL BOXES AND WIRING HARNESES



<u>Ref</u>	<u>Description</u>	<u>Part#</u>	<u>Qty</u>
1	Power lead tractor	006-5650A	1
2	Power lead baler	006-5650B	1
3	Communication harness (baler)	006-5650D	1
4	Communication harness (tractor)	006-5650C	1
5	Ram mount	001-2012H	1
6	Terminating resistor	006-5650Z	2
7	Precision information processor	006-5671LS	1
8	End of bale sensor	006-7400	1
9	End of bale sensor bracket	001-4648	1
10	Display	006-5670	1
NP	Dust cap	006-5650PLUGS	1