


Parts breakdown for control boxes and wiring harnesses



<u>Ref</u>	<u>Description</u>	<u>Part#</u>	<u>Qty</u>
1	Power lead tractor	006-5650A	1
2	Power lead baler	006-5650B	1
3	Communication harness (baler)	006-5650D	1
4	Communication harness (tractor)	006-5650C	1
5	Ram mount	001-2012H	1
6	Terminating resistor	006-5650Z	1
7	Precision information processor	006-5671LS2	1
8	Pump controller harness	006-5650F	1
8	Pump controller harness (Krone balers only)	006-5650F2	1
9	End of bale sensor	006-7400	1
10	Pump controller	006-5672	1
11	End of bale sensor bracket	001-4648	1
12	End of bale sensor bracket (Krone)	001-4648K	1
13	End of bale sensor bracket (Krone)	001-4648K2	1
14	Display	006-5670	1
15	Suction cup mount	001-2012SCM	1
16	Dust plug kit	006-5650PLUGS	1
17	PIP shield	001-5650X	1
18	Keyed power	006-5650K	1
19	(Optional) End of bale ext. harness	006-7400EXT	1