


## Parts Breakdown for 600RB Series Control and Harnesses



<u>Ref</u>	<u>Description</u>	<u>Part Number</u>	<u>Qty</u>
1	End Of Bale Sensor	006-7400	1
2	Terminating Connector w/ green cap	006-5650Z	1
3	DCP Shield/Cover	001-5650X	1
4	DCP Main Control LS 600 AUTO	006-6671RB	1
5	DCP Baler Harness 15 FT	006-6650LS	1
6	DCP Tractor Harness	006-6650TM	1
7	Dust Plugs	006-5651PLUGS	1
8	Round Baler End of Bale Bracket	001-4648RB	1
9	Key Switch Wire	006-5650K	1
10	ISOBUS Tractor Plug	006-6670A	1
NP	End of Bale Ext. Harness	006-7400EXT	1