


## 676 Parts Breakdown for Saddle and Tank



<u>Ref</u>	<u>Description</u>	<u>Part #</u>	<u>Qty</u>
1	TANK	005-9209	1
2	LEFT HANGER EXTENSION	001-6708L	1
3	RIGHT HANGER EXTENSION	001-6708R	1
4	LEFT TANK HANGER	001-6709L	1
5	RIGHT TANK HANGER	001-6709R	1
6	CROSS BRACE	001-6709X	1
7	STALK PROTECTOR	001-6709S	1
NP	TANK BREATHER	005-9022B2	1
NP	TANK CAP – 4"	005-9209C	1
NP	TANK RING – 4"	005-9209R	1
NP	TANK GASKET – 4"	005-9209G	1

Tanks 2010 and older had two lids. The lid that is no longer used replacement part number is 005-9207B2