



Heater Skid Assembly – Front View



<u>Ref</u>	<u>Description</u>	<u>Part #</u>	<u>Qty</u>
1	Front Heat Shield	001-7215E	1
2	Sight Gauge Hose	002-9709	1
3	3/8"x3/8 Fitting	003-EL3838BF	2

Heater Skid Assembly – Rear View



<u>Ref</u>	<u>Description</u>	<u>Part #</u>	<u>Qty</u>	<u>Ref</u>	<u>Description</u>	<u>Part #</u>	<u>Qty</u>
1	Diesel Tank	001-7212		NP	Warmup Valve Assembly	Refer to Breakdown	
2	Heat Shield Bracket	001-7215B	2	NP	Fuel Filter Assembly	Refer to Breakdown	
3	Heat Shield Brkt Rear	001-7215C	2	NP	H1 Inlet Assembly	Refer to Breakdown	
4	Heat Shield	001-7215A	2	NP	H1 Outlet Assembly	Refer to Breakdown	
5	Heater Skid	001-7213	1	NP	1/4" (I.D.) Fuel Hose	002-9711	
6	Skip Clamp Plate	001-7214	6	NP	3/8" (I.D.) Fuel Hose	002-9710	
7	1/2"-13 Flange Nut	Hardware	12	NP	1/4" Hose Clamp	003-9001	8
8	1/2"-13 Flange Bolt	Hardware	12	NP	Mini Hose Clamp	003-9002	4
9	1/4"x1/4" Fitting	003-A1414BF	2	NP	Hi Temp Valve Bracket	001-7224C	1
10	1/4"x1/4" Elbow	003-EL1414BF	2	NP	Burner Gasket - Large	007-7209GL	4
NP	Fuel Outlet Assembly	Refer to Breakdown		NP	Fuel Filter Element	006-7209F	2
NP	Fuel Return Assembly	Refer to Breakdown		NP	Heat Shield Top	001-7215F	1
NP	Fuel Filter (Serial# 0009 & Up)	007-7209FFE		NP	Heater Coil	007-7200COILKIT	
NP	Fuel Filter (Serial# Pre-0008)	007-7208FFA		NP	High Pressure Filter	002-4320E	