



Parts Breakdown

Parts Breakdown for Tank, Saddle and Saddle Legs



<u>Ref</u>	<u>Description</u>	<u>Part Number</u>	<u>Qty</u>	<u>Ref</u>	<u>Description</u>	<u>Part Number</u>	<u>Qty</u>
1	Tank	005-9218	1	9	Right saddle leg	001-6707MR	1
2	1/2" tank fitting	005-9104	2	10	1/2" hose	002-9001	2
3	Elbow	003-EL1212	2	NP	Not Pictured:		
4	Tank straps	001-6707P	2	NP	Elbow	003-EL3434	1
5	Tank saddle	001-6707N	1	NP	Elbow	003-EL3412	1
6	Handrail	001-6707HR	1	NP	3/4" tank fitting	005-9100	2
7	Tank lid	005-9022H	1				
8	Left saddle leg	001-6707ML	1				