


Parts Breakdown 9214 Transfer Pump



<u>Ref</u>	<u>Description</u>	<u>Part #</u>	<u>Qty</u>	<u>Ref</u>	<u>Description</u>	<u>Part Number</u>	<u>Qty</u>
1	Telescoping Suction Tube	003-TP1005	1	14	1/4-20 x 1/2" Bolt	NA	4
2	Carrier	001-4572	1	15	1" Hose Clamp	003-9007	4
3	Dust Shield	003-TP1006	1	16	1" MPT Nipple	003-M100100	1
4	Mini Teflon Roll	003-TP1002	2	17	3/4" MPT x 1" HB Elbow	003-EL34100	1
5	Collar Clamp	003-TP1007	1	18	1" MPT x 1" HB Straight	003-A100100	4
6	Nozzle Ball Valve	003-TP1008	1	19	Butress Tank Adapter	003-TP1003	1
7	2" NPT Adapter	003-TP1004	1	20	Pump Probe w/ O-Ring	003-TP1001	1
8	1" Ball Valve	002-2210	2	21	Bulk Cap 6" w/ Breather	005-9204PC	1
9	Female Coupler	002-2204L	1	22	12VDC 15GMP Pump	007-7000	1
10	Male Coupler	002-2204O	1	23	Pump Flange	003-TP1009	1
11	Valve Bracket	001-6702I	1	NP	1" EVA Hose (clear)	002-9013	5 ft
12	1" Plug	002-2204M	1	NP	1" EPDM Hose (black)	003-TP1010	12 ft
13	1/4" Lock Washer	NA	4				