


PARTS BREAKDOWN FOR CONTROL BOX AND WIRING HARNESES



<u>Ref.</u>	<u>Description</u>	<u>Part#</u>
1	Power lead tractor	006-4640A
2	Power lead baler	006-4660R
3	Baler mounted processor	006-4671SS
4	Communication harness (baler)	006-4660S
5	Communication harness (tractor)	006-4660N
6	Ram mount	001-2012H
7	462 Terminal	006-4670
NP	Dust Plugs	006-4660PLUGS