

PARTS BREAKDOWN FOR CONTROL BOXES AND WIRING HARNESES



<u>Ref</u>	<u>Description</u>	<u>Part#</u>	<u>Qty</u>
1	Power & communication tractor	006-5650T	1
2	Pump controller harness (550 & 545)	006-5650FC	1
2	Pump controller harness (551)	006-5650F2	1
3	Power & communication baler	006-5650SS	1
4	Pump controller	006-5672	1
5	Precision Information Processor (PIP)	006-5671SS	1
6	Terminating resistor	006-5660Z	1
7	Ram mount	001-2012H	1
8	Display	006-5670	1
9	End of bale & stroke counter sensor	006-7400	2
10	End of bale bracket (Model 551 & 545)	001-4648SS	1
10	End of bale bracket (Model 550)	001-4648SC	1
NP	Stroke counter bracket (Model 545)	001-4648RB	1
NP	Stroke counter bracket (Model 550)	001-4648SI	1
NP	Splitter	006-7400Y	1
NP	Key switch wire	006-5650K	1
NP	Dust plug kit	006-5651PLUGS	1
NP	Suction cup mount	001-2012SCM	1
NP	PIP shield	001-5650X	1
NP	Not pictured		