



Parts Breakdown for Control Boxes and Wiring Harnesses



| <u>Ref</u> | <u>Description</u> | <u>Part#</u> | <u>Qty</u> |
|------------|----------------------------------|---------------|------------|
| 1 | Power & communication tractor | 006-6650TM | 1 |
| 2 | Pump controller harness | 006-5650FC | 1 |
| 3 | Power & communication baler | 006-6650LS | 1 |
| 4 | Pump controller | 006-5672 | 1 |
| 5 | Dual Channel Processor (DCP) | 006-6671RB | 1 |
| 6 | Terminating resistor | 006-5660Z | 1 |
| 7 | ISOBUS Tractor Plug | 006-6670A | 1 |
| 8 | Bale rate timer | 006-7400 | 1 |
| 9 | Bale rate timer bracket | 001-4648RB | 1 |
| 10 | Bale rate timer sensor extension | 006-7400EXT | 1 |
| NP | Key switch wire | 006-5650K | 1 |
| NP | Dust plug kit | 006-5651PLUGS | 1 |

Optional Touch Screen Display (TSD) and Bluetooth Receiver



| | | |
|---|----------------------|-------------|
| 1 | Touch Screen Display | 006-6670 |
| 2 | Suction Cup Mount | 001-2012SCM |
| 3 | RAM Mount | 001-2012H |
| | Complete Kit | 030-5670A |
| 4 | Bluetooth Receiver | 030-6672A |

