

## 10. Baler Harness/Wiring Installation for AGCO with Baler Interface

- A. The **Baler Power/Communication Harness** (006-6650LS2) will attach to the open port of the Tractor **Harness** (006-6650TM) and run back to the Dual Channel Processor (DCP-006-6671LS). Connect the large plug of the Baler Power/Communication Harness (006-6650LS2) to the bottom (shorter side) of the DCP. Attach **Baler Interface Harness** (006-6650VA) in between the short whip cable hardwired to the DCP and the main Power/Communication Harness (006-6650LS2). Make sure Active Terminator removed from the back underside of the baler is attached to the Baler Interface Harness (006-6650VA).
- B. Install terminating resistor (006-5650Z) to port labeled **Modular Port** on Pump Controller (006-5672).
- C. Attach moisture and bale rate harness (006-7303H) and end of bale harness (006-7400) to the DCP.
- D. Attach the Pump Control Harness (006-5650FM) between the Pump Controller (006-5672) and the DCP (006-6671LS). Connect Keyed Power Extension harness (006-5650K) to a keyed power source.
  - a. When using Bluetooth Receiver (030-6672A) or optional Touch Screen Display (030-5670A). Connect either option to Communication Harness (006-6650TM) in place of the ISO adapter (shown below) and connect the keyed power wire to a keyed power source on tractor.
- E. Note: the Optional Port and the Data Transfer Port are not used in this application.

